



USER & MAINTENANCE GUIDE

MULTI DOME[®]

DISCLAIMER – WARNING ⚠

READ THIS DOCUMENT BEFORE USING THE PRODUCT. IMPROPER USE OF THE PRODUCTS CAN CAUSE DAMAGE TO EQUIPMENT OR PROPERTY, SERIOUS PERSONAL INJURY, OR DEATH.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS DOCUMENT ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS DOCUMENT ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE LIMITED WARRANTY FOR THE PRODUCTS ARE SET FORTH IN THE TERMS OF SALES AND DELIVERY AND ARE INCORPORATED HEREIN BY THIS REFERENCE. THIS USER GUIDE IS PROVIDED “AS IS” WITHOUT ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED.

IN NO EVENT SHALL REHAU-BEHR A/S BE LIABLE FOR ANY ECONOMIC LOSS OR LOSS OF PROFIT, OR INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES OR LOSSES OR DAMAGES ARISING OUT OF IMPROPER USAGE OR INSTALLATION OR ADJUSTMENT, NEGLIGENCE, ACCIDENT OR FAILURE TO CLEAN AND MAINTAIN PRODUCT AS SET FORTH IN THE USER GUIDE AND/OR TECHNICAL ADJUSTMENT INSTRUCTIONS, EVEN IF REHAU-BEHR A/S HAS BEEN EXPRESSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Thank you for choosing a quality product from REHAU-BEHR!

This User & Maintenance Guide applies to the MULTI DOME® glass lids.

Before using the product, please continue reading the instructions covered in this User Guide and save it for future reference.



1. PRODUCT INFORMATION

1.1. All products from REHAU-BEHR A/S are made of high quality materials and excellent craftsmanship and are safe to use according to European Legislation.

1.2. The MULTI DOME® glass lids are intended to be used as covers for commercial horizontal refrigerators and freezers in public sales and display areas.

1.3. The MULTI DOME® glass lids are designed for air conditioned environments where temperature is maintained below 25°C and humidity below 60% R.H.

1.4. The MULTI DOME® glass lids works with coolers ($\geq 0^{\circ}\text{C}$) and freezers ($\geq -24^{\circ}\text{C}$).



2. OPERATION

2.1. Simply push or pull the handle to open or close the MULTI DOME® glass lids.

2.2. During restocking, open the sliding glass fully and load the goods, be careful not to scratch the glass.

2.3. The load limit of the commercial refrigerator must be respected after installation of the MULTI DOME® glass lids.



**Do not place any items, boxes, baskets or stand on top of the MULTI DOME® glass lids or profiles.
It will cause damage beyond repair and make the product unsafe!**





3. CARE AND CLEANING

- 3.1. Every week, clean glass and sliding tracks using a soft microfiber cloth and a mild cleaning agent (i.e. window cleanser).
- 3.2. Do not use harsh or abrasive detergents (i.e. solvent, acidic, ammoniac, chloric or oil based).
- 3.3. Do not use steam or high pressure water.
- 3.4. Spare parts and guidance are available upon request.



Click **here** or scan the QR code to access our video cleaning guide



4. TROUBLESHOOTING

- 5.1. If glasses steam up or water condensates on the top of the glasses, do the following:
 - 5.1.1. For freezer cabinets, verify that the air flow velocity is below 0,3- 0,5 m/sec. and that the temperature is above -24°C. If not, conduct a technical adjustment of the freezer.
 - 5.1.2. Make sure the ambient climate is below 25°C and that humidity is below 60% R.H. If this is not the case, condensation cannot be avoided. REHAU-BEHR recommends air conditioned environments for best performance.



5. END OF LIFE AND DISPOSAL

- 6.1. The MULTI DOME® glass lids have an expected lifetime of 300.000 openings or 10 years.
- 6.2. When disassembling the MULTI DOME® lids, all glass should be removed and disposed of first.
- 6.3. The MULTI DOME® glass lids are free from dangerous substances (RoHS), and may be disposed of in regular way following local legislation.